







顶板/云台部分
Top / camera mount




GPS部分
GPS




标准相机通用套件
Universal camera Kit




机架机身部分
Bottom/Main body




RED 相机套件
RED camera Kit




摄像头部分
Camera lens cage



电池快拆板部分
Quick release battery plate



ZCAM 相机套件
ZCAM camera Kit



ProTek60 Pro

机架组装示意图

Frame Assembly Guide

1. M3*35网纹铝柱 M3*35 Al. standoff	x4	24. M2*4半圆头内六角螺丝 M2*4 hex screw	x6	47. 高频滤波硅胶垫 High frequency damper silicon pad	x6	70. M1.6*12 内六角螺丝 M1.6*12 hex screw	x4	ZCAM/RED 相机套件 ZCAM/RED camera kit	
2. M2*25网纹铝柱 M2*25 Al. standoff	x2	25. M3*22网纹铝柱 M3*22 Al. standoff	x2	48. 通用贴纸V3(附赠) Sticker(gift)	x1	71. M2*8 内六角自攻螺丝 M2*8 self-tapping hex screw	x8	88. M3*6半圆头内六角螺丝 M3*6 hex screw	x8
3. M3*8网纹铝柱 M3*8 Al. standoff	x12	26. LED灯显LOGO TPU LED logo insert	x1	49. 电池固定板 Battery fix pad	x1	标准相机通用套件 Standard camera Kit		89. M4*10 平头内六角螺丝 M4*10 Grub hex screw	x12
4. M3*6内六角螺丝 M3*6 hex screw	x30	27. BB响/蜂鸣器座子 TPU Buzzer TPU holder	x1	50. 电池防滑垫 Battery Pad	x1	72. M3x6半圆头内六角螺丝 M3x6 hex screw	x12	90. M4*9*1尼龙垫片 M4*9*1 Nylon washer	x12
5. M3*8内六角螺丝 M3*8 hex screw	x42	28. 摄像头硅胶侧板(一对) Camera vibration dampers silicone	x1	51. 天空端支架TPU(附赠) DJI air unit bracket TPU(gift)	x2	73. M3*6 沉头内六角螺丝 M3*6 countersunk hex screw	x6	91. 1/4快装板螺丝 1/4 screw for quick release	x2
6. M3*10内六角螺丝 M3*10 hex screw	x4	29. O3 转接板 Adapter plate CNC	x1	52. Taurus X8 云台限位板(附赠) Taurus X8 gimbal plate(gift)	x1	74. M4*10 平头内六角螺丝 M4*10 Grub hex screw	x6	92. M4*10沉头内六角螺丝 M4*10 countersunk hex screw	x6
7. M3*12内六角螺丝 M3*12 hex screw	x2	30. 起落架 TPU Landing gear TPU	x4	53. 内六角七字扳手(附赠) Hex Key Wrench(gift)	x1	75. M4*14 平头内六角螺丝 M4*14 Grub hex screw	x4	93. 12.9级 1/4 半圆头内六角螺丝 12.9 grade 1/4 hex screw	x8
8. M3*8 沉头内六角螺丝 M3*8 countersunk hex screw	x12	31. 图传天线座 TPU Antenna(HD) TPU	x2	54. 梅花开口两用扳手(8/10)(附赠) Open end wrench (8/10)(gift)	x1	76. M4*9*1 尼龙垫片 M4*9*1 Nylon washer	x8	94. 20*400电池扎带 20*400 Battery strap	x2
9. M3*16沉头内六角螺丝 M3*16 countersunk hex screw	x2	32. 接收机座 TPU Receiver TPU	x1	55. M5 内六角螺丝刀套筒(附赠) M5 hex screwdriver(gift)	x1	77. 1/4 快装板螺丝 1/4 screw for quick release	x2	95. CNC固定座A有螺纹 CNC bracket A black threadless	x2
10. M3*28沉头内六角螺丝 M3*28 countersunk hex screw	x4	33. 共用 GPS座 TPU GPS TPU	x1	56. 相机镜头承托海绵(附赠) Camera lens support plate(gift)	x1	78. 20*400电池扎带 20*400 Battery strap	x2	96. CNC 固定座B CNC bracket B black	x2
11. M3*4杯头内六角螺丝 M3*4 Cup head hex screw	x2	34. GPS座侧板 TPU Horiz.900ant+GPS TPU	x1	57. 20*295 电池扎带 双头可粘 20*295 Double velcro battery strap	x2	79. 20*500电池扎带 双头可粘 20*500 Double velcro battery strap	x2	97. 相机防滑格纹硅胶垫A Camera anti-skidding plaid silicone pad A	x1
12. M2*6内六角螺丝 M2*6 hex screw	x8	35. T型天线座 TPU T-Type Antenna TPU	x1	58. LED圆灯珠+线材长65mm LED light + wire 65mm	x1	80. CNC固定座A无螺纹 CNC fixed seat A threadless	x2	98. 相机防滑格纹硅胶垫B Camera anti-skidding plaid silicone pad B	x1
13. M2*7内六角螺丝 M2*7 hex screw	x4	36. 电池滑槽定位座 TPU Battery slot TPU	x1	59. M5 内六角螺丝刀套筒(附赠) M5 hex screwdriver(gift)	x1	81. CNC固定座A有螺纹 CNC fixed seat A threaded	x2	99. 垫片硅胶垫 Gasket silicone pad	x2
14. M2*8带垫内六角螺丝 M2*8 hex screw	x4	37. 保护罩 Prop guard	x4	60. CNC电池滑槽按键 CNC battery slot button	x2	82. CNC 固定座B CNC fixed seat B	x4	100. 相机侧板硅胶垫 Camera spacer silicone pad	x4
15. M2*12沉头内六角螺丝 M2*12 countersunk hex screw	x4	38. 条形EVA棉A(附赠) EVA sponge A(gift)	x2	61. CNC侧板 CNC cam plate	x2	83. 相机防滑格纹硅胶垫A Camera anti-skidding plaid silicone pad A	x1	101. 相机固定侧板A Camera Fixed spacer A	x1
16. M6*20伞头内六角螺丝 M6*20 hex screw	x6	39. 条形EVA棉B(附赠) EVA sponge B(gift)	x2	62. 机架部件底板 Bottom plate	x1	84. 相机防滑格纹硅胶垫B Camera anti-skidding plaid silicone pad B	x1	102. 相机固定侧板B Camera Fixed spacer B	x1
17. ϕ 4*M3*4内六角塞打螺丝 ϕ 4*M3*4 Hexagon plug screw	x2	40. EVA部件A EVA part A	x1	63. 机架部件顶板 Top plate	x1	85. 相机固定底板 Camera fixed bottom plate	x1	103. 云台侧板A(ZCAM/RED) Gimbal spacer A(ZCAM/RED)	x1
18. ϕ 4*M3*6内六角塞打螺丝 ϕ 4*M3*6 Hexagon plug screw	x4	41. EVA部件B EVA part B	x1	64. 电池滑槽固定件 Battery release mechanism	x1	86. 云台侧板A Gimbal spacer A	x1	104. 云台侧板B(ZCAM/RED) Gimbal spacer B(ZCAM/RED)	x1
19. 3*5*6 双通尼龙柱 3*5*6 Double nylon cylinder	x2	42. EVA部件C EVA part C	x2	65. 脚架侧板A Landing gear spacer A	x4	87. 云台侧板B Gimbal spacer B	x1	105. 相机固定板 Camera fixed plate	x1
20. M6*16*1金属垫片 M6*16*1 Metal pad	x12	43. 电机线 集线管(附赠) Motor weir(gift)	x4	66. 脚架侧板B Landing gear spacer B	x4			106. 相机垫片 Camera Gasket	x2
21. M6*6.6防松螺母 M6*6.6 lock nut	x6	44. 公插 XT90E-M Male adaptor XT90E-M	x1	67. 相机云台板 Gimbal plate	x1				
22. M3 六角尼龙螺母 M3 Nylon nut	x8	45. 弹簧0.8*5*10 Spring 0.8*5*10	x2	68. GPS座侧板 GPS mount cam plate	x1				
23. M3 防松自紧螺母 M3 self tightening lock nut	x8	46. 弹簧0.6*5*10 Spring 0.6*5*10	x2	69. BEC 固定板 BEC mounting plate	x1				